

ACCESSORIES

MANUAL ACCESSORIES

■ SJ80-811 Lower Bracket

Lower Bracket for mounting
Screwjack to outer frame.

Available in Mill Finish or Brass.



■ SJ80-83111 Lower Bracket

Lower Bracket for mounting
Screwjack to outer frame.

Available only in Mill Finish.



■ SJ170-236 Lower Bracket

Lower Bracket for mounting
Screwjack to outer frame.

Available only in Mill Finish.



■ SJ170-25036 Lower Bracket

Lower Bracket for mounting
Screwjack to outer frame.

Available only in Mill Finish.



■ SJ80-7910 Upper Bracket

Upper Bracket for mounting
Screwjack to opening vent.

Available only in Mill Finish.



■ SJW80G Upper Bracket

Upper Bracket for mounting
Screwjack to opening vent.

Available only in Mill Finish.



■ SJ169-236 Upper Bracket

Upper Bracket for mounting
Screwjack to opening vent.

Available only in Mill Finish.



■ SJ198 Upper Bracket

Upper Bracket for mounting
Screwjack to opening vent.

Available in Mill Finish or Brass.



■ SJ173 Upper Bracket

Upper Bracket for mounting
Screwjack to opening vent.

Available only in Mill Finish.



ACCESSORIES

MANUAL ACCESSORIES

■ SJ169 Upper Bracket

Lower Bracket for mounting
Screwjack to opening vent.

Available in Mill Finish or Brass.



■ SJ192 Upper Bracket

Upper Bracket for mounting
Screwjack to opening vent.

Available only in Mill Finish.

