

# WLA 110

## ROOM THERMOSTAT



### DESCRIPTION

Room thermostat for temperature control via automatic opening and closing of windows. The room thermostat is installed on the wall. No special tools are required.

Application. Room thermostat WLA 110 is used for control via WindowMaster control systems. The desired temperature is set on the thermostat scale. When the temperature exceeds the temperature set, the room thermostat sends a signal to the control unit, which activates the window actuators. When the temperature has dropped to the desired level, the windows will automatically close again. If window operation through a keypad is desired, the sensor function may be switched off on the switch, positioned on the front of the thermostat.

### TECHNICAL DATA

Primary Voltage	24V DC max 1.25A
Measuring Range	+5°C - +30°C
Operating Condition	+5°C - +50°C
Size	75 x 75 x 25 mm
Protection Type	IP 30
Delivery	1 x Room Thermostat
Cable Size	3-Core

## PART CODES

WLA110 - WLA 110 Room Thermostat

## APPLICATION



COMFORT  
VENTILATION

## COMPATIBLE WITH



WUC 102 - Control Unit



WCC 310/320-STANDARD - Control Unit



WCC 310/320-PLUS - Control Unit



WSC 310/320-STANDARD - Control Unit



WSC 310/320-PLUS - Control Unit